




How to install the 64 Bit Driver for 64 Bit Windows

You need the 64 bit drivers from Proceq to connect an Equotip 3 device to a PC with an USB cable on an x64 System. This is a short tutorial on how to install this driver.


START THE DEVICE MANAGER




LOCATE THE UNKNOWN DEVICE




RIGHT CLICK AND SELECT UPDATE DRIVER SOFTWARE




SELECT BROWSE MY COMPUTER FOR DRIVER SOFTWARE




POINT TO THE FOLDER CONTAINING THE DRIVER FILES



PRESS INSTALL



WAIT UNTIL INSTALLING IS FINISHED



THE DRIVER IS NOW SUCCESSFULLY INSTALLED

